

DuPont™ Tyvek® Cargo Cover Installation

Quick & Simple
Installation in 1
Minute!



Step 1



Step 2



Step 3



Step 4



Step 5

Step 1 - Place Tyvek® Cargo Cover (optional) bottom sheet directly on skid/pallet

Step 2 - Build your cargo load as you would normally

Step 3 - Unfold Tyvek® Cargo Cover on top of load

Step 4 - Evenly slide the Tyvek® cover over the cargo load down to meet the top of the bottom sheet.

Step 5 - Tyvek® Cover is secured by the imbedded elastic band. No taping required.

Installation Video – link to youtube

<https://www.youtube.com/watch?v=b4Hhof9uXFM>

Please note: Stretch wrap can be used under the cover to secure the load.

However, **DO NOT** apply any type of film **OVER** the Tyvek® cover .



Tyvek.